

CUMPAN

Cockpit Assistant

FANTIC Caballero 700 Model year 2024

Installation suggestion from BEROTEC



Customer example - No guarantee for functionality

FANTIC Caballero 700

Position display

Mounted on the handlebar with optional display holder



Connection of the RPM signal ("SENS" setting: BIKE)

Speed signal pick-up at the two-pole plug (gray cable), on the left side of the engine, behind the inverter.



FANTIC Caballero 700

Position engine temperature sensor (M10x1)

Oil temperature (M10x1) taken together with the oil pressure on the right-hand side of the engine housing.



Power supply

Power connection under the tank on the white two-pin plug using the gray adapter plug supplied

