

CUMPAN

Tachometer and Cockpit Assistant

YAMAHA XT660X
Model year: 2004

Installation suggestion from Steffen



Customer example – No guarantee of functionality

YAMAHA XT660X

Display position

On the handlebars, below the speedometer.




Pickup of the RPM signal

(Sensor setting: **UNI**

Value "UNI": **12**


At the crankshaft position sensor - blue-yellow cable on the two-pole plug, which can be found on the left at the height of the airbox. The branch connector used here has a grease filling that protects the contact point against moisture.



YAMAHA XT660X

Location of engine temperature sensor

Replaces the oil drain plug on the left side of the engine. The cable is fixed between the engine and the sprocket cover so that it cannot be damaged by the sprocket.



Power connection

Can be connected to the fuse box (fuse: "Ignition") using the optional fuse branch - replaces the original 10A fuse. <https://berotec.de/product/fuse-branch/?lang=en>

